

Application: ewrite.exe Version 1.01

Description

ewrite.exe is a PC Console Application, for 64 bit Windows operating systems, used to read and correct RD8K1 menu setting values.

ewrite.exe has to be used on a PC where ITCC or RD Manager applications are installed to ensure that USB drivers are installed.

Note: ITCC and RD Manager applications must NOT be running when ewrite.exe is executed.

Zip File ewrite.zip contains the following files:

- 1) ewrite.exe
- 2) wdapi1140.dll is a dll used by ewrite.exe for USB communication with a RD8K1 Locator.
- 3) Command prompt that starts in folder C:\zTmp

Instructions to install and use ewrite.exe

- 1) Install RD Manager if it is not already installed on the 64-bit PC.
- 2) Create folder c:\ztmp
- 3) Extract ewrite.zip files to folder c:\ztmp
- 3) In folder c:\ztmp, double Click on Command Prompt.
- 4) In the command console type "ewrite" and press enter to run ewrite.exe
- 5) Please follow the on screen instructions provided by ewrite.exe
- 6) Uploading to the locator will take 1-2 seconds only. Once the command screen indicates the correct serial number of the device, and indicates "eprom OK", turn off the locator and then disconnect it from the PC